TI-Nspire™ Software Script

Updating the handheld OS (Tutorial A17)

http://www.atomiclearning.com/k12/en/movie/86402/play_window?type=Tutorial&sid=2421

[00:00:00.00]
It's important that you make sure your TI-Nspire or TI-Nspire CAS handheld is running the current operating system,

[00:00:07.00]
and that you also have your TI-Nspire Software up-to-date.
Updating the OS will keep your saved documents, but it's

[00:00:15.00]
a good idea to back up important documents to your computer
regularly. If you haven't done so, open the TI-Nspire computer

[00:00:23.00]
software. I'll plug my handheld into the computer's USB
port and turn it on. Now make sure you have an active Internet

[00:00:32.00]
connection on your computer, and then we can click on the
Content tab at the very top, and then on the left side

[00:00:39.00]
of the window under Resources, we can click and select
our Connected Handheld. Next we can click on the Help menu

[00:00:48.00]
and you'll see that you have the option to check for software
updates here, as well as the Handheld OS updates. Be sure

[00:00:55.00]
that you do both periodically. In this case, I'll choose
Check for Handheld OS Update. You'll see a dialog box appear

[00:01:03.00]
after a few seconds either letting you know that your handheld
is up-to-date or prompting you to install the current OS.

[00:01:10.00]
If the OS is out-of-date, you have a few options before
you update it. The first check box will install the OS

[00:01:17.00]
on the current, active handheld. The second check box will save a copy of the OS to a location on your computer's

[00:01:24.00]
hard drive. You can also use the Browse button to specify this location. The third check box will automatically check

[00:01:32.00]
for updates. Once you've got those settings the way you want them, you can click Continue. Next you'll see the

[00:01:40.00]
License Agreement dialog box. I'll click the top Radio button to accept the terms of the License Agreement and

[00:01:47.00]
then click Continue. Once the update is complete, the handheld will display a message letting you know that it's safe

[00:01:52.00]
to unplug and reboot the device.

[00:01:57.00]